



RF-BM-ND08A nRF52811

Multi-Protocols Module Supporting BLE, Bluetooth Direction Finding, Thread

Version 1.0

Shenzhen RF-star Technology Co., Ltd.

May 25th, 2023

All rights reserved. Those responsible for unauthorized reproduction will be prosecuted.

1 Device Overview

1.1 Description

RF-BM-ND08A is an RF module based on Nordic SoC nRF52811 with ARM® Cortex®-M4 32-bit processor. It integrates a 32.768 kHz and a 32 MHz crystal, an LC filter, an antenna matching and antenna options of a meander line inverted-F PCB antenna and a half-hole interface. It supports Bluetooth® 5.1 Low Energy, Bluetooth Direction Finding and Thread, and can be preprogrammed with a serial interface communication protocol for simple programming. It includes a range of analog and digital interfaces such as PDM, PWM, UART, SPI and I²C. It features low power consumption, compact size, robust connection distance, and rigid reliability. 1.27-mm pitch stamp stick package for easy assembling and cost-effective PCB design. RF-BM-ND08A is pin-to-pin compatible with RF-BM-ND08/ND08C/ND08I.

1.2 Key Features

- RF Features
 - Bluetooth® 5.1 low energy
 - Bluetooth Direction Finding
 - Thread
 - 12-bit, 200 ksps ADC
 - 16 GPIOs
 - 4-channel PWM
 - Digital microphone interface (PDM)
- Angle-of arrival (AoA) and angle-of-departure (AoD) direction finding
 - SPI master/slave
 - I2C master/slave
 - UART (CTS/RTS)
- TX power: -20 to +4 dBm
- ARM® Cortex®-M4 32-bit processor, 64 MHz
- Supply voltage range 1.7 V ~ 3.6 V
- Memory
 - 192 kB flash
 - 24 kB RAM
- Support for concurrent multi-protocol
- Peripherals
 - Programmable peripheral interconnect (PPI)
 - Quadrature decoder (QDEC)
 - AES HW encryption
 - Real-time counter (RTC)
 - Transmission Range: 80 m
 - Dimension: 15.2 mm x 11.2 mm x 1.7 mm

1.3 Applications

- Internet of Things (IoT)
- Mouse
- Keyboard
- Mobile HID
- Industrial lighting
- Commercial lighting
- Retail
- Home Automation
- Beacons
- Health and medical
- Virtual reality headsets
- Wearables
- Connectivity device in multi-chip solutions

1.4 Functional Block Diagram




Figure 1. Functional Block Diagram of RF-BM-ND08A

1.5 Part Number Conventions

The part numbers are of the form of RF-BM-ND08A where the fields are defined as follows:




Figure 2. Part Number Conventions of RF-BM-ND08A

Table of Contents

1 Device Overview	1
1.1 Description.....	1
1.2 Key Features	1
1.3 Applications	1
1.4 Functional Block Diagram	2
1.5 Part Number Conventions	2
Table of Contents.....	3
2 Module Configuration and Functions	4
2.1 Module Parameters.....	4
2.2 Module Pin Diagram	5
2.3 Pin Functions.....	5
3 Specifications	7
3.1 Recommended Operating Conditions	7
3.2 Handling Ratings.....	7
4 Application, Implementation, and Layout.....	8
4.1 Module Photos	8
4.2 Recommended PCB Footprint.....	8
4.3 Schematic Diagram.....	9
4.4 Antenna.....	9
4.4.1 Antenna Design Recommendation	9
4.4.2 Antenna Output Mode Modification.....	10
4.5 Basic Operation of Hardware Design	10
4.6 Trouble Shooting.....	11
4.6.1 Unsatisfactory Transmission Distance.....	11
4.6.2 Vulnerable Module.....	11
4.6.3 High Bit Error Rate	12
4.7 Electrostatics Discharge Warnings	12
4.8 Soldering and Reflow Condition.....	12
5 Optional Package Specification	14
5 Revision History	16
6 Contact Us.....	17

2 Module Configuration and Functions

2.1 Module Parameters

Table 1. Parameters of RF-BM-ND08A

Chipset	nRF52811
Supply Power Voltage	1.7 V ~ 3.6 V, recommended to 3.3 V
Frequency	2402 MHz ~ 2480 MHz
Transmit Power	-20.0 dBm ~ +4.0 dBm (Typical: 0 dBm)
Receiving Sensitivity	-97 dBm sensitivity in 1 Mbps Bluetooth® low energy mode -104 dBm sensitivity in 125 kbps Bluetooth® low energy mode (long range)
Power Consumption	4.6 mA peak current in TX (@ 0 dBm) 4.6 mA peak current in RX
Data Rate	Bluetooth® 5.2: 2 Mbps, 1 Mbps, 500 kbps, and 125 kbps IEEE 802.15.4-2006: 250 kbps Proprietary 2.4 GHz: 2 Mbps, 1 Mbps
GPIO	16
Crystal	32 MHz, 32.768 kHz
RAM	24 KB
Flash	192 KB
Package	SMT packaging (1.27-mm half-hole pitch stamp stick)
Frequency Error	±20 kHz
Dimension	15.2 mm x 11.2 mm x 1.7 mm
Type of Antenna	PCB antenna, half-hole interface
Operating Temperature	-40 °C ~ +85 °C
Storage Temperature	-40 °C ~ +125 °C

2.2 Module Pin Diagram




Figure 3. Pin Diagram of RF-BM-ND08A

2.3 Pin Functions

Table 2. Pin Functions of RF-BM-ND08A

Pin	Name	Chip Pin	Pin Type	Description
1	ANT	-	-	Antenna interface
2	GND	GND	GND	Ground
3	VCC	VCC	VCC	Power supply 1.7 V ~ 3.6 V, Recommend 3.3 V
4	P25	P0.25	Digital I/O	General purpose I/O
5	P17	P0.17	Digital I/O	General purpose I/O
6	P21/RST	P0.21/RESET	Digital I/O	General purpose I/O. Reset, active low.
7	P13	P0.13	Digital I/O	General purpose I/O
8	P28	P0.28/AIN4	Digital or Analog	General purpose I/O, analog capability
9	P27	P0.27	Digital I/O	General purpose I/O
10	P26	P0.26	Digital I/O	General purpose I/O
11	P09	P0.09	Digital I/O	General purpose I/O
12	P10	P0.10	Digital I/O	General purpose I/O

13	P19	P0.19	Digital I/O	General purpose I/O
14	P20	P0.20	Digital I/O	General purpose I/O
15	P05	P0.05/AIN3	Digital or Analog	General purpose I/O, analog capability
16	P07	P0.07	Digital I/O	General purpose I/O
17	P06	P0.06	Digital I/O	General purpose I/O
18	P08	P0.08	Digital I/O	General purpose I/O
19	P03	P0.03/AIN1	Digital or Analog	General purpose I/O, analog capability

Note:

SWD debugging ports are on the bottom side of the module, which is not pulled out in the stamp half hole way, please refer to the module pin diagram for details.



3 Specifications

3.1 Recommended Operating Conditions

The functional operation does not guarantee performance beyond the limits of the conditional parameter values in the table below. Long-term work beyond this limit will affect the reliability of the module more or less.

Table 3. Recommended Operating Conditions of RF-BM-ND08A

Items	Condition	Min.	Typ.	Max.	Unit
Operating Supply Voltage	Battery Mode	1.7	3.3	3.6	V
Operating Temperature	/	-40	+25	+85	°C
Environmental Hot Pendulum	/	-20		+20	°C/min

3.2 Handling Ratings

Table 4. Handling Ratings of RF-BM-ND08A

Items	Condition	Min.	Typ.	Max.	Unit
Storage Temperature	Tstg	-40	+25	+125	°C
Human Body Model	HBM		±4000		V
Moisture Sensitivity Level			3		
Charged Device Model			±750		V

4 Application, Implementation, and Layout

4.1 Module Photos




Figure 4. Photos of RF-BM-ND08A

4.2 Recommended PCB Footprint





Figure 5. Recommended PCB Footprint of RF-BM-ND08A (mm)

4.3 Schematic Diagram



- (3) It is best to hollow out the antenna position in the following figure to ensure that the S11 of the module is minimally affected.




Figure 7. Recommendation of Antenna Layout

Note: The hollow-out position is based on the antenna used.

4.4.2 Antenna Output Mode Modification

The module has two antenna output modes, which are onboard PCB antenna and stamp half-hole output (ANT pin, see pin function table for details).

The default delivery is the onboard PCB antenna, L1 position (1NH) is welded. If you want to change to a half-hole antenna output, disconnect the L1 position capacitor. The location of L1 is shown in the figure below.



Figure 8. Antenna Output Mode Change

4.5 Basic Operation of Hardware Design

1. It is recommended to offer the module with a DC stabilized power supply, a tiny power supply ripple coefficient, and reliable ground. Please pay attention to the correct connection between the positive and negative poles of the power supply. Otherwise, the reverse connection may cause permanent damage to the module;
2. Please ensure the supply voltage is between the recommended values. The module will be permanently damaged if the voltage exceeds the maximum value. Please ensure a stable power supply and no frequently fluctuated voltage.
3. When designing the power supply circuit for the module, it is recommended to reserve more than 30% of the margin, which is beneficial to the long-term stable operation of the whole machine. The module should be far away from the power electromagnetic, transformer, high-frequency wiring, and other parts with large electromagnetic interference.

4. The bottom of the module should avoid high-frequency digital routing, high-frequency analog routing, and power routing. If it has to route the wire on the bottom of the module, for example, it is assumed that the module is soldered to the Top Layer, the copper must be spread on the connection part of the top layer and the module, and be close to the digital part of the module and routed in the Bottom Layer (all copper is well-grounded).
5. Assuming that the module is soldered or placed in the Top Layer, it is also wrong to randomly route the Bottom Layer or other layers, which will affect the spurs and receiving sensitivity of the module to some degrees;
6. Assuming that there are devices with large electromagnetic interference around the module, which will greatly affect the module performance. It is recommended to stay away from the module according to the strength of the interference. If circumstances permit, appropriate isolation and shielding can be done.
7. Assuming that there are routings of large electromagnetic interference around the module (high-frequency digital, high-frequency analog, power routings), which will also greatly affect the module performance. It is recommended to stay away from the module according to the strength of the interference. If circumstances permit, appropriate isolation and shielding can be done.
8. It is recommended to stay away from the devices whose TTL protocol is the same 2.4 GHz physical layer, for example, USB 3.0.

4.6 Trouble Shooting

4.6.1 Unsatisfactory Transmission Distance

1. When there is a linear communication obstacle, the communication distance will be correspondingly weakened. Temperature, humidity, and co-channel interference will lead to an increase in communication packet loss rate. The performances of ground absorption and reflection of radio waves will be poor when the module is tested close to the ground.
2. Seawater has a strong ability to absorb radio waves, so the test results by the seaside are poor.
3. The signal attenuation will be very obvious if there is a metal near the antenna or the module is placed inside the metal shell.
4. The incorrect power register set or the high data rate in an open-air may shorten the communication distance. The higher the data rate, the closer the distance.
5. The low voltage of the power supply is lower than the recommended value at ambient temperature, and the lower the voltage, the smaller the power is.
6. The unmatchable antennas and modules or the poor quality of the antenna will affect the communication distance.

4.6.2 Vulnerable Module

1. Please ensure the supply voltage is between the recommended values. The module will be permanently damaged if the voltage exceeds the maximum value. Please ensure a stable power supply and no frequently fluctuated voltage.
2. Please ensure the anti-static installation and the electrostatic sensitivity of high-frequency devices.

- Due to some humidity-sensitive components, please ensure suitable humidity during installation and application. If there is no special demand, it is not recommended to use at too high or too low temperature.

4.6.3 High Bit Error Rate

- There are co-channel signal interferences nearby. It is recommended to be away from the interference sources or modify the frequency and channel to avoid interferences.
- The unsatisfactory power supply may also cause garbled. It is necessary to ensure the power supply's reliability.
- If the extension wire or feeder wire is of poor quality or too long, the bit error rate will be high.

4.7 Electrostatics Discharge Warnings

The module will be damaged for the discharge of static. RF-star suggests that all modules should follow the 3 precautions below:

- According to the anti-static measures, bare hands are not allowed to touch modules.
 - Modules must be placed in anti-static areas.
 - Take the anti-static circuitry (when inputting HV or VHF) into consideration in product design.
- Static may result in the degradation in performance of the module, even causing the failure.

4.8 Soldering and Reflow Condition

- Heating method: Conventional Convection or IR/convection.
- Solder paste composition: Sn96.5 / Ag3.0 / Cu0.5
- Allowable reflow soldering times: 2 times based on the following reflow soldering profile.
- Temperature profile: Reflow soldering shall be done according to the following temperature profile.
- Peak temperature: 245 °C.

Table 5. Temperature Table of Soldering and Reflow

Profile Feature	Sn-Pb Assembly	Pb-Free Assembly
Solder Paste	Sn63 / Pb37	Sn96.5 / Ag3.0 / Cu0.5
Min. Preheating Temperature (T_{min})	100 °C	150 °C
Max. Preheating Temperature (T_{max})	150 °C	200 °C
Preheating Time (T_{min} to T_{max}) (t_1)	60 s ~ 120 s	60 s ~ 120 s
Average Ascend Rate (T_{max} to T_p)	Max. 3 °C/s	Max. 3 °C/s
Liquid Temperature (T_L)	183 °C	217 °C
Time above Liquidus (t_L)	60 s ~ 90 s	30 s ~ 90 s
Peak Temperature (T_p)	220 °C ~ 235 °C	230 °C ~ 250 °C
Average Descend Rate (T_p to T_{max})	Max. 6 °C/s	Max. 6 °C/s

Time from 25 °C to Peak Temperature (t_2)	Max. 6 minutes	Max. 8 minutes
Time of Soldering Zone (t_p)	20±10 s	20±10 s




Figure 9. Recommended Reflow for Lead-Free Solder

5 Optional Package Specification

The default package method is **by tray**. If you need the modules to be shipped by tape & reel, pls contact us in advance.




Figure 10. Default Package by Tray




Figure 11. Package by Tape & Reel

5 Revision History

Date	Version No.	Description
2020.09.02	V1.0	The initial version is released.
2023.05.25	V1.0	Update MSL level. Update the Shenzhen office address.

Note:

1. The document will be optimized and updated from time to time. Before using this document, please make sure it is the latest version.
2. To obtain the latest document, please download it from the official website: www.rfstariot.com and www.szrfstar.com.



6 Contact Us

SHENZHEN RF-STAR TECHNOLOGY CO., LTD.

Shenzhen HQ:

Add.: Room 502, Podium Building No. 12, Shenzhen Bay Science and Technology Ecological Park, Nanshan District, Shenzhen, Guangdong, China, 518063

Tel.: 86-755-8632 9829

Chengdu Branch:

Add.: N2-1604, Global Center, North No. 1700, Tianfu Avenue, Hi-Tech District, Chengdu, Sichuan, China, 610095

Tel.: 86-28-8692 5399

Email: sunny@szrfstar.com, sales@szrfstar.com

Web.: www.rfstariot.com, www.szrfstar.com

